

BELL202 MODEM (USB interface)	MODEL COP-HU
---	---------------------

BEFORE USE

Thank you for choosing M-System. Before use, please check contents of the package you received as outlined below. If you have any problems or questions with the product, please contact M-System's Sales Office or representatives.

■ **PACKAGE INCLUDES:**

- Bell202 modem(1)
- Driver software CD(1)

■ **MODEL NO.**

Confirm Model No. marking on the product to be exactly what you ordered.


■ **INSTRUCTION MANUAL**

This manual describes necessary points of caution when you use this product. The driver software is downloadable at M-System's web site: <http://www.m-system.co.jp>

CONNECTION

- Connect the USB connector end of the COP-HU to the PC.
- Connect the polarity-insensitive test clips across the receiving resistor of the target device.
- Install the driver software following instructions included in the CD.
- DO NOT disconnect the USB connector while PC Configurator software (e.g. 27HUCFG) program is running. If there are errors in the PC Configurator software by disconnecting/reconnecting the modem, restart the PC.

■ **CONNECTION EXAMPLE**



⚠ Warning
 DO NOT use the COP-HU in explosive atmosphere.
 DO NOT connect the COP-HU to intrinsic safety circuits.

EXTERNAL DIMENSIONS unit: mm (inch)

