

CLAMP SET	MODEL VOCP
------------------	-------------------

BEFORE USE

Thank you for choosing M-System. Before use, check the contents of the package you received as outlined below.
 If you have any problems or questions on the product, please contact M-System's Sales Office or representatives.

■ MODEL NO.

The Model VOCP is a clamp set used for connecting M-System's Position Transmitter to a linear motion valve. Applicable Position Transmitters' maximum stroke is of 330 mm with the input angle within -22.5 to +22.5°. Confirm the specifications of the Position Transmitter.

■ PACKAGE INCLUDES:

- Clamp (A) (1)
- Clamp (B) (1)
- Lever (1)
- Hexagonal bolts (M6x50) (2)
- Spring washer (for M6) (2)
- Washer (for M6) (2)


INSTALLATION

1) ATTACHING THE CLAMP

Put the valve (or actuator) stem between the clamps and fasten them with the attached two bolts at an appropriate position.
 Adjust the lever length to meet the position of the Position Transmitter.

2) CONNECTING THE POSITION TRANSMITTER

Refer to the Instruction Manual of the Position Transmitter for connecting the clamp set with the Position Transmitter.



M-SYSTEM WARRANTY

M-System warrants such new M-System product which it manufactures to be free from defects in materials and workmanship during the 36-month period following the date that such product was originally purchased if such product has been used under normal operating conditions and properly maintained, M-System's sole liability, and purchaser's exclusive remedies, under this warranty are, at M-System's option, the repair, replacement or refund of the purchase price of any M-System product which is defective under the terms of this warranty. To submit a claim under this warranty, the purchaser must return, at its expense, the defective M-System product to the below address together with a copy of its original sales invoice. THIS IS THE ONLY WARRANTY APPLICABLE TO M-SYSTEM PRODUCT AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. M-SYSTEM SHALL HAVE NO LIABILITY FOR CONSEQUENTIAL, INCIDENTAL OR SPECIAL DAMAGES OF ANY KIND WHATSOEVER.

M-System Co., Ltd., 5-2-55, Minamitsumori, Nishinari-ku, Osaka 557-0063 JAPAN, Phone: (06) 6659-8201, Fax: (06) 6659-8510, E-mail: info@m-system.co.jp